


Microsoft Xbox Hookup

Connecting to a television and VCR setup



STEREO VCR SETUP

You do not need to change the existing connection between the VCR and TV. If your TV is connected to a VCR and the VCR has composite (integrated) video input, you can use the standard AV cable included with the Xbox to connect to the VCR. It's that simple!

Connect the color-coded connectors to the corresponding jack on the VCR: yellow to yellow (video in), red to red (right audio in), and white to white (left audio in).

FOR MONO VCR SETUP

For monaural VCRs, connect either the right or left audio connector to the audio jack.

If using AV cords to input on VCR, the VCR will need to be set to line input or aux etc. on the VCR.

For more info go to <http://www.xbox.com/>